

WEAVER[®] JACK CORP.

M O D E L W A - 1 4 0 B

**PARTS BREAKDOWN
SERVICE MANUAL**

FOR PARTS, PLEASE CONTACT:


Castle EQUIPMENT
COMPANY
 SINCE 1950

**TOLL-FREE: 888-274-8490
TELEPHONE: 815-458-6216
FAX: 815-458-9350
E-MAIL: CASTLE@AMERITECH.NET
WEBSITE: WWW.CASTLEEQUIPMENT.COM
P.O. Box 3; BRAIDWOOD, IL 60408**


140B TRANSMISSION JACK

(CONVERSION KIT INCLUDES ALL ITEMS LISTED THIS PAGE)

(KJ-115)



WA-140B Trans.



Repair Parts List WA-140B

Item No.	Part No.	Description	Item No.	Part No.	Description
1.	S-17000	Pump Cover	57.	M-2196	Lower Collar
2.	S-6655	Rd. Hd. Machine Screw 1/4-20	58.	S-17385	Link Pin
3.	AS-17397	Foot Pedal Assembly	59.	S-2612	Connector
4.	S-7573	Hex Nut 3/8-24	60.	S-20620	GT Ring
5.	S-12774	Snap Ring	61.	S-20886	Handle Grip
6.	S-17386	Yoke Pin	62.	S-17407	O-Ring
7.	S-17474	Spring	63.	S-18071	Pipe Plug
8.	AS-17384	Pump Link	64.	M-2071	Reservoir Cap
9.	S-17473	Link Pin	65.	S-175	Hex Hd. Cap Screw
10.	S-1699	Release Packing Nut	66.	S-18577	Name Plate
11.	S-11	Release Packing	67.	S-2296	Cylinder Cap Gasket
12.	S-1805	Pipe Plug 1/8	68.	S-15064	Handle Tube
13.	S-1700	Release Lever	69.		
14.	S-10	Ball PSE 1/4	70.	S-595	Hex Nut
15.	S-9	PSI Cup	71.	S-11563	Washer
16.	S-18	PSI Spring	72.	S-6579	Rd. Hd. Machine Screw
17.	S-7	Pressure Set Screw 1/2-20	73.	S-17468	Flat Hd. Mach. Screw
18.	S-8	Welch Plug 9/16	74.	AS-17467	Line Cover
19.	S-12580A	Packing Nut 1-1/4	75.	AS-17467A	Line Cover
20.	S-12588	Packing (3 set)	76.	AS-17439	Caster
21.	S-17383	Pump Pin	77.	S-105	Hex Hd. Cap Screw
22.	S-12774	Snap Ring	78.	AS-20603	Inner Cylinder Assembly
23.	S-12582	Pump Rod 7/8	79.	S-14110	Roll Pin
24.	S-24648	Pump Cup	80.	AS-20613	Cylinder Bearing & Sleeve
25.	S-12583	Pump Cup Washer	81.	AS-20610	Inner Cylinder
26.	S-1863	Hex Nut 5/16-24	82.	S-20621	O-Ring
27.	S-20978	Pump Tube	83.	M-2195	Upper Locking Collar
28.	S-543	Lockwasher 1/4	84.	S-20619	GT Ring
29.	S-5	Allenhead 1/4-20 3-1/2	85.	AS-20599	Column Piston Assembly
30.	S-1805	Pipe Plug 1/8	86.	S-15694	Roll Pin
31.	S-9309	Ball Chamber Plug	87.	AS-20602	Piston Bearing & Sleeve
32.	S-2594	Ball Chamber Gasket	88.	S-20598	Piston Rod
33.	S-2750	Ball 1/2	89.	AS-24507	Head Assembly
34.	S-10069	Ball Weight 1/4	90.	M-1931	Screw Knob
35.	S-2505	Ball 5/16	91.	S-12610	Tilting Screw
36.	S-15	Release Ball	92.	M-1933	Tilting Bracket
93.	S-17	Release Spring	93.	M-2274	Hinge
38.	S-6	Release Tension Screw 7/16-20	94.	S-25169	Spacers
39.	S-20	Welch Plug	95.	S-20234	Wing Nut
40.	S-17445A	Tube	96.	AS-20616	Frame Assembly
41.	S-20945	Close Nipple 1/8	97.	S-20217	Screw Pivot Bar
42.	S-20944	90° Elbow 1/4 Tube to 1/8 Pipe	98.	S-20235	Straight Link Coil Chain
43.	S-24343	O-Ring Static Seal	99.	S-20218	Swivel Pin
44.	S-17388	Intake Line	100.	S-20219	Swivel Bracket
45.	AS-20970A	Release Shaft	101.	S-12617	Roll Pin
46.	AS-20962A	Release Pedal Assembly	102.		
47.	S-595	Hex Nut 3/8-16	103.		
48.	S-20622	O-Ring	104.	AS-12606	Saddle Screw Assembly
49.	S-20988	Circuit Block	105.	S-12613	Tilting Pin
50.	S-17387A	Pump Spacer	106.	S-12615	Adapter Nut
51.	S-19909	Release Clamp Washer	107.	S-12625	Wing Nut
52.	S-3165	Cap Screw 3/8-16-1-1/2	108.	S-24503	Tilting Pin
53.	S-3277	Int. Lockwasher	109.	S-12630	Carriage Bolt
54.	S-14	Release Packing Washer	110.	AS-20439	Adapter Foot
55.	S-17384	Link	111.	AS-24490	Table Assembly
56.	S-17387	Pin Spacer			